



P552SJ Repair Guide

BLOCK DIAGRAM

P452SJ/ SCHEMATIC Revision




POWER FLOW




POWER ON SEQUENCE

AC-IN Mode

P452SJ Power On Sequence Diagram Rev.0.1



Signal Measure Point-Bottom



Signal Measure Point-Top

